



LevelOne GTL-2690 Routing Configuration

1. Create VLAN

- a. Go to VLAN > 802.1Q VLAN > VLAN static List
- b. Create VLAN 10 for Internet
- c. Create VLAN 20 for CCTV
- d. Click Apply

Home	VLAN Static List				
SNTP SNMP Segurity	Current: 1, DefaultVlan, Enabled	A	New: VLAN ID (1-4093)		
Port Address Table	10, Internet, Enabled 20, CCTV, Enabled	< <add Remove</add 	VLAN Name		
 Spanning Tree Subscription Subscription 			Status	Enabled	
E Basic Informatic Current Table Static List					
Static List					
 Port Configurati Trunk Configura 					
■ 802.1Q Tunnel ■ Tunnel Port Cor					
e. Go to VLAN > 802.1	 LQ VLAN > Static Table	!			

- f. Assign port 1-4 to VLAN 10 > Click Apply
- g. Assign port 5-96 to VLAN 20 > Click Apply

VLAN: 10 -

Name	Internet
Status	Enabled

Port	Tagged	Untagged	Forbidden	None	Trunk Member
1	0	۲	0	0	
2	0	۲	0	0	
3	0	۲	0	0	
4	0	۲	0	0	
5	0	0	0	۲	





- h. Go to VLAN > 802.1Q VLAN > Port Configuration
- i. Assign PVID 10 to port 1-4
- j. Assign PVID 20 to port 5-96
- k. Click Apply

VLAN Port Configuration

Port	PVID	Acceptable Frame Type	Ingress Filtering	GVRP Status				
1	10	ALL 💌	Enabled	Enabled				
2	10	ALL 💌	Enabled	Enabled				
3	10	ALL 💌	Enabled	Enabled				
4	10	ALL 💌	Enabled	Enabled				
5	20	ALL 💌	Enabled	Enabled				
6	20	ALL 💌	Enabled	Enabled				
7	20	ALL 💌	Enabled	Enabled				

Note : 2 x Join Timer < Leave Timer < LeaveAll Timer

2. Create Routing Interface

- a. Go to IP > General > Global Setting
- b. Enable IP Routing status > Click Apply
- c. Go to IP > General > Routing Interface
- d. Create Routing Interface on VLAN 10 > Click Set IP Configuration
- e. Click

Apply

Routing Interface

VLAN	10 💌
IP Address Mode	Static Primary
IP Address	192.168.254.200
Subnet Mask	255.255.255.0

Set IP Configuration Remove IP Address

Restart DHCP





- f. Create Routing Interface on VLAN 20 > Click Set IP Configuration
- g. Click Apply

Routing Interface

VLAN	20 💌
IP Address Mode	Static Primary
IP Address	172.16.0.254
Subnet Mask	255.255.0.0
Subnet Mask	255.255.0.0

Set IP Configuration Remove IP Address

Restart DHCP

h. Please Note* Please assign gateway 172.16.0.254 to IP Camera and Recorder.

3. Enable Routing Protocal

- a. Go to routing protocol > RIP > General Settings
- b. Enable RIP Routing Process
- c. Choose Global RIP Version to RIPV2 > Click Apply

General Settings

Global	
RIP Routing Process	Enabled
Global RIP Version	RIPv2 -
Timer	
Update (15-60 seconds)	30
Timeout (Update*6)	180
Garbage Collection (Update*4)	120





- d. Go to routing protocol > RIP > Network Address
- e. Add Subnet Address 172.16.0.0 > Click Add
- f. Add Subnet Address 192.16.254.0 > Click Add
- g. Click Apply

Network Addresses

Current:			New:
172.16.0.0 192.168.254.0	*	< Add Remove	Subnet Address

- h. Go to routing protocol > RIP > Interface Settings
- i. Setting VLAN 10 Interface > Click Apply

Interface Settings

VLAN	10 💌
Receive Version	RIPv1 or RIPv2
Send Version	RIPv1 Compatible -
Instability Prevention	Split Horizon 💌
Authentication Type	No Authentication 💌
Authentication Key	





j. Setting VLAN 20 Interface > Click Apply

Interface Settings

VLAN	20 💌
Receive Version	RIPv1 or RIPv2
Send Version	RIPv1 Compatible -
Instability Prevention	Split Horizon 💌
Authentication Type	No Authentication 💌
Authentication Key	

4. Enable RIPv2 Routing protocol on the router.

level" o n c						Eng	ılish 💌
	R's MAIN	MENU 📲 S	tatus	😾 Wizard	M Advanced	F	Logout
BASIC SETTING	Ś	FORWARDING RULES	Ś		ADVANCED SETTI	IG 🔂	TOOLBOX
System Time		Routing Table					[Help]
System Log		Item			Setting		
Dynamic DNS	+ Dj	▶ Dynamic Routing					
SNMP	► Static Routing						
* Routing	ID	Destination		Subnet Mask	Gateway	Нор	Enable
Schedule Rule	1	192.168.3.0]	255.255.255.0	192.168.2.2	1	
	2						